

1. GROUP NO.

The 1st one digit indicates " MAIN GROUP NO." and next three digits indicate " SUB GROUP NO."

2. SUB GROUP NAME

This indicates the name of sub group within the main group.

3. PART NAME

Part names are shown in multi-language
(example)

(E).....English (F).....French

(D).....German (S).....Spanish

4. KEY NUMBER

Key number corresponds with the reference number on the illustration.
Key number is not always sequenced.

5. PART NUMBER

The number is assigned to each part.

6. ITC(INTERCHANGEABILITY CODE)

When any part number has been changed due to design modification, this indicates the interchangeability between two part numbers.

*Interchangeability symbols

Y : The old and new parts are interchangeable.

N : The old and new parts are not mutually interchangeable.

O : The new part can be used for the old part but the reverse is not possible.

7. MODEL

This column indicates Drive Type, Engine Type, Transaxle Type, Body Type, Clutch Type, Trim Level.

*Drive type

- L : Left hand dirve

- R : Right hand dirve

- . : Common

* Engine type

- . : Common

- Y : 1.5 SOHC

- V : 1.5 DOHC

- 6 : 1.6 DOHC

- W : 2.0 SOHC

- Z : 2.0 DOHC

- C : 1.4 SOHC

* Trim level.

- EVANDA : SX/CDX

- LEGANZA : SX/CDX

- TACUMA : SE/SX/CDX

- NUBIRA : SE/SX/CDX

- LANOS : S/SE/SX

- LACETTI : S/SX/CDX

- MATIZ : S/SE/CD

- MATIZ(M200) : S/SE/SX

* Transaxle type

- M : Manual transaxle

- A : Automatic transaxle (All)

- G : Automatic transaxle (GMPT)

- Z : Automatic transaxle (ZF)

- . : Common

* Clutch type

- M : Manual clutch

- A : Automatic clutch

- . : Common

* Body type

- 3 H : 3 Door Hatchback

- 4 N : 4 Door Notchback

- 5 H : 5 Door Hatchback

- 5W : 5 Door Station Wagon

"LEVEL" column indicates the expression of applicable trim level.

S : Standard equipment.

O : Option equipment.

A : Available equipment for the special package according to the area regulation.

. : Not applied

