



RJ2110DW 10/30/2004

LACETTI <WESTERN EUROPE>
FUEL TANK

| KEY NO. | | PART NAME | | | | | | | | | | | | | | OPTION | REMARKS | | | | |
|-------------|----------|--------------------|---------|---------|-------------|-------|----|----|-------|----|-----|-------------|-------------|-------------|----------------------------|--------|---------|-----------------|------------------------------|------|----|
| I T C | PART NO. | C H G | MY F | MY T | D R V | MODEL | | | | | | L / R | Q T Y | P N C | P / C O D E | | | EFFECTIVE POINT | | | |
| | | | | | | BODY | | | LEVEL | | | | | | | | | VIN1 | | VIN2 | |
| | | | | | | 4N | 4H | 5W | I | II | III | | | | | | | FROM | TO | FROM | TO |
| 1 | | TANK A-FUEL | | | | | | | | | | | | | | | | | | | |
| | 96553743 | | 04 | 06 | | B | B | B | X | X | X | | 1 | | | | | | &NNJ/NN1 | | |
| 2 | | MODULE A-FUEL PUMP | | | | | | | | | | | | | | | | | | | |
| | 96495969 | CH | 04 | 05 | | B | B | B | X | X | X | | 1 | FS | | | | | &L14/L44&NN1&XSM | | |
| | 96447440 | AD | 06 | 06 | | B | B | B | X | X | X | | 1 | FU | | | | | &L14/L44&NNJ&XSM | | |
| | 96495939 | CH | 04 | 04 | | B | B | . | X | X | X | | 1 | FD | | 994847 | | | &L84&XDP | | |
| O | 96418319 | AD | 04 | 05 | | B | B | B | X | X | X | | 1 | FI | 994848 | 231106 | | | &L84&XDP | | |
| O | 96447440 | AD | 04 | 06 | | B | B | B | X | X | X | | 1 | FU | 231107 | | | | &LDA/L84&NNJ&XDP | | |
| 3 | | RING-O | | | | | | | | | | | | | | | | | | | |
| | 96183170 | | 04 | 06 | | B | B | B | X | X | X | | 1 | | | | | | &NNJ/NN1 | | |
| 4 | | RING-LOCKING | | | | | | | | | | | | | | | | | | | |
| | 96183169 | | 04 | 06 | | B | B | B | X | X | X | | 1 | | | | | | &NNJ/NN1 | | |
| 7 | | STRAP | | | | | | | | | | | | | | | | | | | |
| | 96553801 | | 04 | 06 | | B | B | B | X | X | X | LH | 1 | | | | | | &NNJ/NN1 | | |
| | 96553805 | | 04 | 06 | | B | B | B | X | X | X | RH | 1 | | | | | | &NNJ/NN1 | | |
| 8 | | TUBE A-FUEL FILLER | | | | | | | | | | | | | | | | | | | |
| | 96553811 | | 04 | 06 | | B | B | B | X | X | X | | 1 | JA | | | | | &NNJ/NN1 | | |
| 11 | | CLAMP | | | | | | | | | | | | | | | | | | | |
| | 96313240 | | 04 | 06 | | B | B | B | X | X | X | | 1 | | | | | | &NNJ/NN1 | | |
| 12 | | SHIELD-FUEL FILLER | | | | | | | | | | | | | | | | | | | |
| | 96553823 | | 04 | 06 | | B | B | B | X | X | X | | 1 | | | | | | | | |
| 13 | | NUT | | | | | | | | | | | | | | | | | | | |
| | 94515147 | | 04 | 06 | | B | B | B | X | X | X | | 3 | | | | | | | | |
| 20 | | NUT | | | | | | | | | | | | | | | | | | | |
| | 94515107 | | 04 | 06 | | B | B | B | X | X | X | | 2 | | | | | | | | |
| 22 | | SCREW | | | | | | | | | | | | | | | | | | | |
| | 94520301 | | 04 | 06 | | B | B | B | X | X | X | | 4 | | | | | | | | |
| 23 | | BOLT | | | | | | | | | | | | | | | | | | | |
| | 94500400 | CH | 04 | 06 | | B | B | . | X | X | X | | 1 | | | | | | | | |
| 36 | | SENDER-FUEL | | | | | | | | | | | | | | | | | | | |
| | 96499272 | CH | 04 | 04 | | B | B | . | X | X | X | | 1 | | | 943306 | | | &L14/L44&XSM | | |
| O | 96495799 | CH | 04 | 05 | | B | B | B | X | X | X | | 1 | LS | 943307 | 231106 | | | &L14/L44&XSM | | |
| O | 96447443 | AD | 04 | 06 | | B | B | B | X | X | X | | 1 | LV | 231107 | | | | &L14/L44&NN1/NN4/NN7&XSM | | |
| | 96447441 | | 06 | 06 | | B | B | B | X | X | X | | 1 | LU | 231107 | | | | &L14/L44&NNJ&XSM | | |
| | 96499272 | CH | 04 | 04 | | B | B | . | X | X | X | | 1 | | | 994847 | | | &L84&XDP | | |
| O | 96423726 | CH | 04 | 05 | | B | B | B | X | X | X | | 1 | LI | 994848 | 231106 | | | &L84&XDP | | |
| O | 96447441 | AD | 04 | 06 | | B | B | B | X | X | X | | 1 | LU | 231107 | | | | &LDA/L84&NNJ/NN1/NN4/NN7&XDP | | |