



RJ4950GW 08/05/2005

**LACETTI <WESTERN EUROPE>
POWER STEERING PIPE LINE**

I T C	KEY NO.		PART NAME														OPTION	REMARKS			
	PART NO.	C H G	M Y F	M Y T	D R V	MODEL						L / R	Q T Y	P N C	P / C O D E	EFFECTIVE POINT					
						BODY			LEVEL							VIN1			VIN2		
						4N	4H	5W	I	II	III					FROM			TO	FROM	TO
1 PUMP A-P/STRG																					
	96451409		04	06		B	B	.	X	X	X		1	5E			&L14&N40				
	96451457		04	06		B	B	.	.	.	X		1	FV			&L14&UXA				
Y	96550113	CH	04	06		B	B	B	X	X	.		1	6P	890018		&L44&N40				
	96451970	AD	04	06		B	B	B	X	X	X		1	6E			&LDA/L44&N40				
	96451461		04	06		B	B	B	.	.	X		1	6V			&L44&UXA				
Y	96451988	AD	04	06		B	B	B	.	.	X		1	6T	890018		&LDA/L44&UXA				
	96451419		04	06		B	B	B	.	.	X		1	HE			&L84&N40				
Y	96451991	CH	04	06		B	B	B	.	.	X		1	HU			&L84&N40				
	96450003		04	04		B	X		1	HS	890017		&L84&UXA				
O	96451465	CH	04	05		B	B	B	.	.	X		1	HV	890018		&L84&UXA				
Y	96452858	CH	04	06		B	B	B	.	.	X		1	HT			&L84&UXA				
2 RESERVOIR A-P/STRG OIL																					
O	96452735		04	04		B	.	.	X	X	X		1	J2		921218	&N40/UXA				
	96451797		04	06		B	B	B	X	X	X		1	JR	921219		&N40/UXA				
3 CAP-OIL,RESERVOIR,P/STRG																					
Y	96399757		04	06		B	.	.	X	X	X		1			921218	&N40/UXA				
	96451788		04	06		B	B	B	X	X	X		1		921219		&N40/UXA				
5 RING-O																					
	94535975	CH	04	06		B	B	B	X	X	X		3				&N40/UXA				
10 CLAMP																					
	96451099		04	06		B	B	B	X	X	X		2				&N40/UXA				
11 CLIP																					
	94530057	CH	04	06		B	B	B	X	X	X		2				&N40/UXA				
15 SHIELD-OIL RESERVOIR																					
	96263705		04	06		B	B	B	X	X	X		1				&N40/UXA				
16 BOLT																					
	94500298		04	05		B	B	B	.	X	X		1				&L84&N40/UXA				
17 BRACKET-PUMP,HYD UNIT																					
	96221420		04	05		B	B	B	.	X	X		1				&L84&N40/UXA				
18 BOLT																					
	94500292		04	05		B	B	B	.	X	X		2				&L84&N40/UXA				
20 PIPE A-RTN FLOW																					
	96550111		04	06	L	B	B	B	X	X	X		1	JL			&N40/UXA				
22 CLAMP																					
	96287491		04	06		B	B	B	X	X	.		1				&LDA/L14/L44&N40/UXA				
	96253820		04	05		B	B	B	.	X	X		1				&L84&N40/UXA				
24 GROMMET																					
	96234131		04	06		B	B	B	X	X	.		1				&LAD/L14/L44&N40/UXA				
	96234131		04	06		B	B	B	.	X	X		1				&LAD/L14/L44&N40/UXA				
25 BOLT																					
	94500400		04	06	L	B	B	B	X	X	X		1				&N40/UXA				
26 BRACKET A-P/STRG PIPE																					
	96535369		04	05		B	B	B	X	X	.		1				&L14/L44&N40/UXA				
	96535369		06	06		B	B	B	X	X	X		1				&LDA/L14/L44&N40/UXA				
	96454151	AD	06	06		B	B	B	.	X	X		1				&LDA&N40/UXA				
27 BOLT																					
O	94500906		04	04		B	.	.	.	X	X		1			921218	&L84				
	94500400		04	05		B	B	B	.	X	X		1		921219		&L84&N40/UXA				
39 NUT																					
	94515099		04	06		B	B	B	X	X	.		1				&LDA/L14/L44&N40/UXA				
48 NUT																					
	94515107		04	06		B	B	B	X	X	.		2				&LDA/L14/L44&N40/UXA				
51 PIPE A-PRESSURE																					
	96451205		04	06	L	B	B	B	X	X	.		1	CP			&L14/L44&N40				
	96451207		04	06	L	B	B	B	.	.	X		1	CS			&L14/L44&UXA				
	96450008		04	05	L	B	.	.	.	X	X		1	BP	943306		&L84-UXA				
O	96451818		04	05	L	B	B	B	.	X	X		1	HL	943307		&L84&N40				
	96450006		04	04	L	B	X		1	BS	943306		&L84&UXA				
O	96451819		04	05	L	B	B	B	.	.	X		1	SL	943307		&L84&UXA				
	96451905	AD	06	06	L	B	B	B	.	X	X		1	8L			&LDA&N40				
	96451907	AD	06	06	L	B	B	B	.	.	X		1	EL			&LDA&UXA				
55 BOLT																					
	94500302		04	05		B	B	B	.	X	X		1				&L84&N40/UXA				
58 PIPE A-SUCT																					
	96550118	CH	04	05		B	B	B	X	X	.		1	SF		053807	&L14/L44&N40/UXA				
O	96451955	AD	04	05		B	B	B	X	X	.		1	F1	053808		&L14/L44&N40/UXA				
	96451955		06	06		B	B	B	X	X	.		1	F1	053808		&LDA/L14/L44&N40/UXA				
	96450005	CH	04	05		B	B	B	.	X	X		1	SH	053807		&L84&N40/UXA				
O	96451967	AD	04	05		B	B	B	.	X	X		1	F2	053808		&L84&N40/UXA				
60 BOLT																					
	94500400		04	06		B	B	B	X	X	X		2				&N40/UXA				
64 SPONGE-OIL RESERVOIR																					
	96263717		04	06		B	B	B	X	X	X		1				&N40/UXA				
69 RESTRICTOR-OIL																					
	96275005		04	06		B	B	B	X	X	X		1				&N40/UXA				

**LACETTI <WESTERN EUROPE>
POWER STEERING PIPE LINE**

KEY NO.		PART NAME																				
I T C	PART NO.	C H G	MY F	MY T	D R V	MODEL						L / R	Q T Y	PNC	P / C O D E	EFFECTIVE POINT				OPTION	REMARKS	
						BODY			LEVEL							VIN1		VIN2				
						4N	4H	5W	I	II	III					FROM	TO	FROM	TO			
	76			NUT																		
	94515147		04	06	B	B	.	X	X	X		2				850264			&N40/UXA			
Y	94515119	CH	04	05	B	.	B	X	X	X		2			850265	039617			&N40/UXA			
Y	94515345	CH	04	05	B	.	B	X	X	X		2			039618	102314			&N40/UXA			
Y	94525655	AD	04	06	B	.	B	X	X	X		2			102315				&N40/UXA			