



RJ8110 10/30/2004

**LACETTI <WESTERN EUROPE>  
AIR DISTRIBUTOR**

KEY NO.		PART NAME														OPTION	REMARKS				
I T C	PART NO.	C H G	M Y F	M Y T	D R V	MODEL						L / R	Q T Y	P N C	P / C O D E			EFFECTIVE POINT			
						BODY			LEVEL									VIN1		VIN2	
						4N	4H	5W	I	II	III							FROM	TO	FROM	TO
<b>1</b>		<b>DUCT-AIR,I/P</b>																			
	96554840		04	06		B	B	B	X	X	.		1		RA					&L14/L44	
	96451400		04	06		B	B	B	.	X	X		1		RB					&LDA/L84/L88	
<b>2</b>		<b>HOSE-DEFROSTER,SIDE</b>																			
	96554846		04	06		B	B	B	X	X	X	LH	1								
	96554847		04	06		B	B	B	X	X	X	RH	1								
<b>3</b>		<b>SCREW</b>																			
	94520326		04	06		B	B	B	X	X	X		6								
<b>8</b>		<b>HOSE-VENT</b>																			
	96554815		04	06		B	.	.	X	X	X		1				933129			&BC2	
Y	96414976		04	06		B	.	.	X	X	X		1			933130				&BC2	
	96414977		04	06		.	B	B	X	X	X		1							&BC1	
<b>9</b>		<b>SCREW</b>																			
	94520326		04	06		B	B	B	X	X	X		2								
	94520326		04	06		B	B	B	X	X	X		4								
<b>18</b>		<b>CONNECTOR A-AIR DISTR</b>																			
	96554674		04	06		B	B	B	X	X	X	LH	1							&C35	
	96554675		04	06		B	B	B	X	X	X	RH	1							&C35	
<b>19</b>		<b>DUCT A-LEG ROOM,RR</b>																			
	96554672		04	06		B	B	B	X	X	X	LH	1							&C35	
	96554673		04	06		B	B	B	X	X	X	RH	1							&C35	